# TOP AND CABINET PARTS

**For Models: GST9679PW3, GST9679PG3, GST9679PB3**
**(White/Grey) (Biscuit/Gold) (Black/Grey)**

AUTOMATIC
WASHER




FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# TOP AND CABINET PARTS

**For Models: GST9679PW3, GST9679PG3, GST9679PB3**
**(White/Grey) (Biscuit/Gold) (Black/Grey)**

| Illus. No. | Part No. | DESCRIPTION |
|---|---|---|
| 1 | | Literature Parts |
| | 3958075 | Installation Instructions |
| | 8578232 | Use & Care Guide |
| | 3955903 | Feature Sheet |
| | 3957477 | Energy Guide |
| | 8565442 | Wiring Diagram |
| **Following May Be Purchased** | | |
| **DO−IT−YOURSELF REPAIR MANUALS** | | |
| | 4313896 | Manual, Washer |
| 2 | | Top |
| | 8543447 | White |
| | 8543448 | Biscuit |
| | 8543450 | Black |
| 3 | 62750 | Spacer, Cabinet To Top (4) |
| 4 | 357213 | Nut, Push−In (2) |
| 5 | | Cabinet |
| | 63424 | White |
| | 3954357 | Biscuit |
| | 3954788 | Black |
| 6 | 62780 | Clip, Top & Cabinet & Rear Panel (2) |
| 7 | 3976348 | Cabinet−Sound Damper (3) |
| 8 | 3351614 | Screw, Ground |
| 9 | 3357011 | Screw, 10−16 x 1/2 |
| 11 | 8318084 | Switch, Lid |
| 13 | 355274 | Screw, Lid Hinge Mounting (4) |
| 14 | 21097 | Pad, Lid Hinge (2) |
| 15 | 8559336 | Hinge, Lid (L.H.) |
| 16 | 91770 | Hinge, Lid (R.H.) |
| 18 | 8319539 | Bearing, Lid Hinge (2) |
| 19 | | Lid |
| | 8558401 | White |
| | 8558402 | Biscuit |
| | 8558403 | Black |
| 20 | 9724509 | Bumper, Lid (2) |
| 21 | | Handle, Lid |
| | 3956012 | (For GST9679PW2) |
| | 3956011 | (For GST9679PG2) |
| 22 | 3956010 | Insert, Handle |
| 28 | 3390631 | Screw, 10−16 x 3/8 (4) |
| 31 | 3956079 | Cover, Dispenser |
| 32 | 8519517 | Dispenser, Bleach |

# CONTROLS AND REAR PANEL PARTS

**For Models: GST9679PW3, GST9679PG3, GST9679PB3**
**(White/Grey) (Biscuit/Gold) (Black/Grey)**




FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# CONTROLS AND REAR PANEL PARTS

**For Models: GST9679PW3, GST9679PG3, GST9679PB3**
**(White/Grey) (Biscuit/Gold) (Black/Grey)**

| Illus. No. | Part No. | DESCRIPTION |
|---|---|---|
| 1 | 3976300 | Washer, Water Inlet Hose (4) (1−1/16 x 5/8) |
| 2 | 694419 | Mini, Buzzer |
| 3 | | Hose, Water Inlet (2) |
| | 8571377 | Blue Coupler |
| | 8571378 | Red Coupler |
| 4 | 303294 | Edge Protector |
| 5 | 8568314 | Strap, Console (2) |
| 6 | 8318015 | Panel, Rear |
| 7 | 62747 | Pad, Rear Panel |
| 8 | 8559373 | Drain Hose Assembly (Includes Illus. Nos. 19 & 33) |
| 9 | 3955765 | Timer, Control (60 Hz.) (Motor Not A Service Part) |
| 10 | 8055003 | Clip, Harness & Pressure Hose |
| 11 | 90767 | Screw, 8−18 x 3/8 |
| 12 | 3366845 | Switch, Water Level |
| 13 | 8544893 | Bracket, Control |
| 14 | 661661 | Cord, Power (Includes Illus. 15) |
| 15 | 3952821 | Strain Relief, Power Cord |
| 16 | | Cap, End (L.H.) |
| | 8271365 | White |
| | 8271368 | Biscuit |
| | 8271367 | Black |
| 17 | 8317975 | Retainer, Harness |
| 18 | 3979347 | Valve, Water Inlet & Thermistor Assy. |
| 19 | 8541668 | Clamp, Hose |
| 20 | 8572718 | Capacitor |
| 21 | 301958 | Clamp, Hose Break |
| 22 | 8317387 | Fuse (In Harness) |
| 23 | 370450 | Clamp, Hose |
| 24 | 387606 | Break, Vacuum |
| 26 | 8519200 | Support, Rear Panel |
| 28 | 8541672 | U−Bend, Drain Hose |
| 29 | 3347868 | Cable Tie |
| 30 | 3363366 | Clamp, Hose |
| 31 | 8317496 | Clamp, Hose |
| 32 | 3951449 | Hose, Pump To Tub (Includes Illus. 30) |
| 33 | 8541667 | Clamp, Hose |
| 34 | 3956080 | Switch, Rotary |
| 35 | 62863 | Screw, 10−16 x 3/8 |
| 36 | 3400818 | Screw, Timer Mounting |
| 37 | 8533990 | Medallion |
| 38 | 8564137 | Switch, Water Temperature (ATC) |
| 39 | | Panel, Console (Includes Illus. 37) |
| | 3956604 | Silver |
| | 3956605 | Gold |
| 40 | 3950356 | Switch, Rotary |
| 41 | 3400073 | Screw, Ground |
| 43 | 8317974 | Hose, Vacuum Break |
| 44 | | Knob, Timer |
| | 8544945 | Silver |
| | 8544946 | Biscuit |
| 45 | | Dial, Timer |
| | 8544947 | White |
| | 8544948 | Biscuit |
| 46 | | Knob, Control |
| | 8544937 | Silver |
| | 8544938 | Biscuit |
| 47 | 8536939 | Clip, Knob |
| 48 | 9740848 | Screw, 8−18 x 1/2 |
| 49 | 388326 | Screw, 8−18 x 1.25 (Panel to Top) |
| 50 | 3351614 | Screw, Ground |
| 51 | | Cap, End (R.H.) |
| | 8271359 | White |
| | 8271362 | Biscuit |
| | 8271361 | Black |
| 55 | 8318046 | Clip, Capacitor |
| 57 | 8541669 | Bucket, Drain Hose (Left Half) |
| 58 | 8541658 | Bucket, Drain Hose (Right Half) |
| 59 | 8539874 | Shield, Suds |
| 60 | 3957254 | Harness, Wiring (For Detail See Pages 9 & 10) |

**FOLLOWING PARTS NOT ILLUSTRATED**

| | |
|---|---|
| 3957361 | Miscellaneous Parts Bag |

# AGITATOR, BASKET AND TUB PARTS

**For Models: GST9679PW3, GST9679PG3, GST9679PB3**
**(White/Grey) (Biscuit/Gold) (Black/Grey)**




FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# AGITATOR, BASKET AND TUB PARTS

**For Models: GST9679PW3, GST9679PG3, GST9679PB3**
**(White/Grey) (Biscuit/Gold) (Black/Grey)**

| Illus. No. | Part No. | DESCRIPTION |
|---|---|---|
| 1 | 63580 | Dispenser Asy. |
| 2 | 358237 | Screw & Washer (5/16−24 x 1) |
| 3 | 3363003 | Clothes Mover |
| 4 | 3951632 | Agitator |
| 5 | 3954507 | Tub Ring & Gasket |
| 6 | 3359585 | Seal, Tub Ring |
| 7 | 3354845 | Clip, Agitator |
| 8 | 8543666 | Washer, Agitator |
| 9 | 3951682 | Cam, Driven |
| 10 | 3366877 | Dog, Agitator Clutch (4) |
| 11 | 3952374 | Bearing−Driven Cam |
| 12 | 21366 | Nut, Spanner |
| 13 | 8526016 | Basket & Balance Ring |
| 14 | 8318246 | Wax Motor |
| 15 | 8519788 | Balance Ring |
| 16 | 8283125 | Tub (Includes Item 25) |
| 17 | 389140 | Block, Basket Drive |
| 18 | 383727 | Gasket, Centerpost |
| 19 | 3347780 | Hose, Pressure Switch |
| 20 | 3951744 | Agitator (Complete Asy.) |
| 21 | 2219077 | Clip, Pressure Switch Hose |
| 22 | 3951608 | Spacer, Thrust |
| 23 | 3354733 | Cap, Barrier |
| 24 | 3348855 | Seal, Inner Cap |
| 25 | 3948705 | Hose, Bleach |
| 26 | 3949550 | Washer |

# BRAKE, CLUTCH, GEARCASE, MOTOR AND PUMP PARTS

**For Models: GST9679PW3, GST9679PG3, GST9679PB3**
**(White/Grey) (Biscuit/Gold) (Black/Grey)**




| Illus. No. | Part No. | DESCRIPTION |
|---|---|---|
| 1 | 388952 | Brake & Drive Tube (Complete) (Refer to Page 11 For Further Breakdown) |
| 2 | 63292 | Washer, Spin Tube Thrust |
| 3 | 62697 | Ring, Spin Tube Support |
| 4 | 63283 | Ring, Retainer |
| 5 | 3951311 | Clutch (Complete) |
| 6 | 3951308 | Band & Lining, Clutch (Includes Illus. 7 & 8) |
| 7 | 62646 | Cap, Clutch Spring (2) |
| 8 | 3946792 | Spring, Clutch |
| 9 | 3360630 | Gearcase (Complete) (Refer To Page 12 For Further Breakdown) |
| 10 | 3357334 | Screw, Gearcase To Base (3) |
| 11 | 62611 | Plate, Motor Mount To Gearcase |
| 12 | 62691 | Grommet, Motor (4) |
| 13 | 285753 | Coupling, Motor & Isolation |
| 14 | 8577374 | Seal |
| 15 | 3355454 | Clip, Anti−Rattle |
| 16 | 3400516 | Screw |
| 17 | 3349637 | Retainer, Motor (2) |
| 18 | 3362089 | Shield, Tub To Motor |
| 19 | 8529935 | Motor, Main Drive |
| 20 | 8529896 | Switch, Main Drive Motor |
| 21 | 8546127 | Retainer, Pump (2) |
| 22 | 3363394 | Pump (Complete) |
| 23 | 3387485 | Screw, 10−16 x 5/8 |
| 24 | 3946532 | Shield, Motor |

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# MACHINE BASE PARTS

**For Models: GST9679PW3, GST9679PG3, GST9679PB3**
**(White/Grey) (Biscuit/Gold) (Black/Grey)**




| Illus. No. | Part No. | DESCRIPTION |
|---|---|---|
| 1 | 3400076 | Screw, Bracket Mounting (10−32 x 5/8) |
| 2 | 64067 | Bracket, Spring Outer (2) |
| 3 | 63907 | Spring Suspension,(3) |
| 4 | 8575214 | Support & Brake, Tub |
| 5 | 64065 | Bracket, Spring Outer (L.F.) |
| 6 | 63466 | Link, Leveling Mechanism (2) |
| 7 | 62597 | Spring, Leveling Mechanism |
| 8 | 62837 | Pin, Knurled |
| 9 | 62596 | Foot, Rear (2) |
| 13 | 3347047 | Bearing, Centerpost (2) |
| 14 | 357409 | Seal, Centerpost (3) |
| 15 | 8318050 | Spring, Counterweight |
| 16 | 62568 | Pad, Plate |
| 17 | 3946509 | Plate, Suspension (Includes Illus. 16) |
| 18 | 3363660 | Pad, Base |
| 19 | 3946512 | Base Assembly (Includes Illus, 6, 7, 8, 9,16,17,18, & 26.) |
| 20 | 8544816 | Sound Absorber |
| 21 | 3359452 | Nut, Lock (2) (3/8−16) |
| 22 | 389102 | Foot, Front (2) |
| 23 | 8577376 | Seal, Centerpost |
| 24 | 285203 | Centerpost Bearing Kit (Includes Illus. 13, 14 & 23) |
| 25 | 63134 | Ring, Sound Deadening |
| 26 | 63806 | Retainer, Suspension Spring |

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# WIRING HARNESS PARTS

**For Models: GST9679PW3, GST9679PG3, GST9679PB3**
**(White/Grey) (Biscuit/Gold) (Black/Grey)**




WH2I

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# WIRING HARNESS PARTS

**For Models: GST9679PW3, GST9679PG3, GST9679PB3**
**(White/Grey) (Biscuit/Gold) (Black/Grey)**

| Illus. No. | Part No. | DESCRIPTION |
|---|---|---|
| 1 | 3349557 | Clip, Harness |
| 2 | 388498 | Clip, Harness |
| 3 | 3347812 | Clip, Harness |
| 4 | 3352501 | Clip, Harness |
| 5 | 90016 | Clip, Harness |
| 6 | 3390496 | Clip, Harness |
| 7 | 389379 | Retainer, (Suds Models) |
| 8 | | Timer, Block Disconnect |
| | 3948614 | White |
| | 352089 | Black |
| 9 | 62889 | Receptacle, Terminal (3−Way) (Lid Switch) (Use Term.94613) Or 94614.) |
| 10 | 353424 | Plug, Terminal (3−Way) (Power Cord) (Use Term.94613) |
| 11 | 62505 | Block, Disconnect (Motor 2 Speed) (Use Term.352088) |
| 12 | 3347243 | Block, Disconnect (Use Term. 352088) |
| 13 | 63523 | Protector |
| 14 | 717252 | Connector (2−Way) (Use Term.94614) |
| 15 | 3352944 | Clip, Harness |
| 16 | 3390423 | Block, Disconnect (12−Way) (Timer) (Use Term. 94613) |
| 17 | 3347730 | Receptacle (6−Way) (Use Term. 94613) |
| 18 | 3349494 | Connector, Etc |
| 19 | 3407125 | E.T.C. Control |
| 20 | 3948617 | Connector (T.P.A.) (3−Circuit) (Lid Switch) |
| 21 | 3360056 | Connector (T.P.A) (3−Circuit) (Pressure Switch) |
| 22 | | Block, Connector |
| | 3354925 | Cold Valve |
| | 3354926 | Hot Valve |

## FOR COMPLETE WIRING HARNESS REFER TO CONTROL AND REAR PANEL PARTS PAGE

WH2I

# BRAKE AND DRIVE TUBE PARTS

**For Models: GST9679PW3, GST9679PG3, GST9679PB3**
**(White/Grey) (Biscuit/Gold) (Black/Grey)**




| Illus. No. | Part No. | DESCRIPTION |
|---|---|---|
| 1 | 388952 | Brake And Drive Tube (Complete) |
| 2 | 62658 | Ring, Thrust |
| 3 | 356427 | Seal, Drive Tube |
| 4 | 64027 | Tube, Basket Drive (Includes Illus. 3, 4, 5 & 9) |
| 5 | 64035 | Ring, Retaining |
| 6 | 64232 | Shoe, Brake (2) |
| 7 | 62703 | "T" Bearing, Spin Tube |
| 8 | 3353956 | Cap, Brake Spring (2) |
| 9 | 387806 | Spring, Brake |
| 10 | 3355360 | Sleeve, Brake Spring |
| 11 | 661516 | Cam, Brake Release |
| 12 | 63022 | Sleeve, Cam |
| 13 | 64194 | Driver, Brake Cam |
| 14 | 90368 | Ring, Retaining |

FOLLOWING PARTS NOT ILLUSTRATED

| | | |
|---|---|---|
| | 285208 | Lubricant (Use Only In Brake Shoe Assembly On Roller & Pin) |

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# GEARCASE PARTS

**For Models: GST9679PW3, GST9679PG3, GST9679PB3**
**(White/Grey) (Biscuit/Gold) (Black/Grey)**




| Illus. No. | Part No. | DESCRIPTION |
|---|---|---|
| 1 | 3360630 | Gearcase (Complete) |
| 2 | 285202 | Cover, Gearcase |
| 3 | 3349985 | Seal, Gearcase Cover |
| 4 | 285195 | Sealer, Gasket (.20 Fl. Oz.) (6 ml) |
| 5 | 63320 | Pinion, Spin (Includes Illus. 25) |
| 6 | 356427 | Seal, Spin Pinion |
| 7 | 389387 | Shaft, Agitator (Complete) |
| 8 | 90369 | Ring, Retaining (2) |
| 9 | 62677 | Retainer, Spring |
| 10 | 62676 | Spring, Agitate |
| 11 | 63273 | Gear, Agitate (Includes 15 and 29) |
| 12 | 62619 | Washer, Agitate Gear |
| 13 | 62580 | Cam Follower (Includes 14) |
| 14 | 62581 | Cam, Agitate (Includes 13) |
| 15 | 285509 | Shaft, Agitator (Includes 11 and 29) |
| 16 | 62618 | Washer, Cam Thrust |
| 17 | 16018 | Bearing, Thrust |
| 18 | 85529 | Ball, Bearing |
| 19 | 389230 | Bottom and Pinion, Gearcase |
| 21 | 285352 | Seal, Thrust Plug |
| 22 | 3351614 | Screw, Gearcase Cover, Mounting (8) (10−24 x 3/8) |
| 23 | 3362552 | Ring, Retaining |
| 24 | 285735 | Washer Kit, Thrust |
| 25 | 62570 | Gear, Spin |
| 26 | 388253 | Neutral Assembly |
| 27 | 3349296 | Rack, Connecting |
| 28 | 62621 | Actuator, Shift |
| 29 | 388815 | Washer, Intermediate |

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# WATER SYSTEM PARTS

**For Models: GST9679PW3, GST9679PG3, GST9679PB3**
**(White/Grey) (Biscuit/Gold) (Black/Grey)**




| Illus. No. | Part No. | DESCRIPTION |
|---|---|---|
| 1 | 285442 | Connector Kit, Plastic Drain Hose |
| 2 | 285321 | Sleeve Kit, (Contains 2 Sleeves) |
| 3 | 370447 | Clamp, Hose |
| 4 | 16272 | Connector, Straight |
| 5 | 285320 | Siphon Break Kit (Not Included) |
| 6 | 65349 | Clamp, Hose |
| 7 | 367031 | Drain Protector (Not Included) |

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# OPTIONAL PARTS (NOT INCLUDED)

**For Models: GST9679PW3, GST9679PG3, GST9679PB3**
**(White/Grey) (Biscuit/Gold) (Black/Grey)**

| Illus. No. | Part No. | DESCRIPTION |
|---|---|---|
| | | **PAINT, TOUCH−UP (1/2oz.)** |
| | 72017 | White |
| | 4392899 | Biscuit |
| | 72032 | Black |
| | | **PAINT, PRESSURIZED SPRAY (12 oz.)** |
| | 350938 | Primer, Gray |
| | 350930 | White |
| | 4392901 | Biscuit |
| | 786020 | Black |
| | | **PAINT, BULK (1 qt.)** |
| | 799344 | White (Uncut) |
| | 4392900 | Biscuit (Uncut) |
| | 786032 | Black (Uncut) |
| | | **OIL** |
| | 350572 | Oil, Gearcase (16 Oz.) |
| | | **LUBRICANT** |
| | 285208 | Lubricant (Use Only in Brake Shoe Assembly On Roller and Pin) |
| | | **SEALER** |
| | 285195 | Sealer, Gasket (.20 Fl. Oz.) (6 ml) |
| | | **ACCESSORY PARTS** |
| | 367031 | Drain Protector |
| | 285320 | Siphon Break Kit |